

# ERP Ecodesign Requirements 2023/826

Category	Product-groupe	Code	Art.-No.	"Off-Mode"	"Standby-Mode"	"Standby-Mode with additional funktion"	"Time of switch equipment to power management"	KA with insulated jug	KA with non-insulated jug	Other coffee maker
								power consumption time	power consumption time	power consumption time
Haushalt / Beauty	Haartrockner	HT	0159	0,053W						
Haushalt / Beauty	Haartrockner	HT	0165	0,074W						
Haushalt / Beauty	Haartrockner	HT	0167	0,054W						
Haushalt / Beauty	Haartrockner	HT	0169	0,143W						
Haushalt / Beauty	Haartrockner	HT	0170							
Haushalt / Beauty	Styler	WL	0241	0W						
Haushalt / Beauty	Styler	WL	0683	0,271W						
Kitchen	Kochplatte	DK	1014	0,03W						
Kitchen	Kochplatte	DK	1031			0.75W				
Kitchen	Kochplatte	KP	1032				0.48W			
Kitchen	Kochplatte	DK	1033			0.7W				
Kitchen	Kochplatte	DK	1042	0,04W						
Kitchen	Kochplatte	KP	1071			0.75W				
Kitchen	Kochplatte	KP	1091	0,04W						
Kitchen	Kochplatte	KP	1092	0,04W						
Microwave & Toasting oven	Back- und Toastofen	TO	2042	0,05W						
Microwave & Toasting oven	Back- und Toastofen	TO	2052	0,03W						
Microwave & Toasting oven	Back- und Toastofen	TO	2056	0,04W						
Microwave & Toasting oven	Back- und Toastofen	TO	2058	0,04W						
Microwave & Toasting oven	Back- und Toastofen	TO	2067	0,04W						
Microwave & Toasting oven	Back- und Toastofen	TO	2068	0,04W						
Microwave & Toasting oven	Back- und Toastofen	TO	2073	0,0W						
Microwave & Toasting oven	Back- und Toastofen	TO	2074	0,0W						
Microwave & Toasting oven	Back- und Toastofen	TO	2077	0,47W						
eBBQ & Funfood	Hörnchenautomat	HA	2082	0,0W						
eBBQ & Funfood	Waffelautomat	WA	2103	0,0W						
eBBQ & Funfood	Waffelautomat	WA	2106	0,35W						
eBBQ & Funfood	Waffelautomat	WA	2114	0,0W						
eBBQ & Funfood	Waffelautomat	WA	2116	0,0W						
eBBQ & Funfood	Waffelautomat	WA	2118	0,0W						
eBBQ & Funfood	Waffelautomat	WA	2125	0,0W						
eBBQ & Funfood	Crepes Maker	CM	2198	0,0W						
eBBQ & Funfood	Crepes Maker	CM	2199	0,0W						
Beverages & Breakfast	Toaster	AT	2217	0,0W						
Beverages & Breakfast	Toaster	AT	2232	0,0W						
Beverages & Breakfast	Toaster	AT	2234	0,0W						
Beverages & Breakfast	Toaster	AT	2286	0,0W						
Beverages & Breakfast	Toaster	AT	2287	0,0W						
eBBQ & Funfood	Raclette-Grill	RG	2347	0,0W						
eBBQ & Funfood	Raclette-Grill	RG	2348	0,0W						
eBBQ & Funfood	Raclette-Grill	RG	2360	0,16W						
eBBQ & Funfood	Raclette-Grill	RG	2365	0,14W						

Category	Product-groupe	Code	Art.-No.	"Off-Mode"	"Standby-Mode"	"Standby-Mode with additional funktion"	"Time of switch equipment to power management"	KA with insulated jug	KA with insulated jug	KA with non-insulated jug	Other coffee maker
									power consumption time	power consumption time	power consumption time
eBBQ & Funfood	Raclette-Grill	RG	2366	0,14W							
eBBQ & Funfood	Raclette-Grill	RG	2370	0,0W							
eBBQ & Funfood	Raclette-Grill	RG	2373	0,0W							
eBBQ & Funfood	Raclette-Grill	RG	2374	0,0W							
eBBQ & Funfood	Raclette-Grill	RG	2375	0,0W							
eBBQ & Funfood	Raclette-Grill	RG	2376	0,0W							
eBBQ & Funfood	Raclette-Grill	RG	2378	0,0W							
eBBQ & Funfood	Raclette-Grill	RG	2379	0,0W	0,27W						
eBBQ & Funfood	Kontaktgrill	KG	2380	0,12W							
eBBQ & Funfood	Kontaktgrill	KG	2389	0,0W							
eBBQ & Funfood	Kontaktgrill	KG	2391	0,31W							
eBBQ & Funfood	Kontaktgrill	KG	2392	0,0W							
eBBQ & Funfood	Kontaktgrill	KG	2394	0,0W							
eBBQ & Funfood	Kontaktgrill	KG	2395	0,38W							
eBBQ & Funfood	Barbecue-Grill Tisch	KG	2397	0,049W							
eBBQ & Funfood	Kontaktgrill	KG	2398		0,176W						
eBBQ & Funfood	Kontaktgrill	KG	2399		0,169W						
Kitchen	Friteuse	FR	2430			0,47W					
Kitchen	Friteuse	FR	2431			0,47W					
Kitchen	Friteuse	FR	2440			0,47W					
Kitchen	Friteuse	FR	2445			0,036W					
Kitchen	Friteuse	FR	2446			0,34W					
eBBQ & Funfood	Sous-Vide-Garer	SV	2451			0,378W					
Kitchen	Friteuse	FR	2452			0,26W					
Kitchen	Friteuse	FR	2453	0,39W							
Kitchen	Friteuse	FR	2461			0,242W					
Kitchen	Friteuse	FR	2462			0,322W					
Kitchen	Friteuse	FR	2463			0,431W					
Kitchen	Friteuse	FR	2464			0,36W					
eBBQ & Funfood	Fondue	FO	2470	0,0W							
eBBQ & Funfood	Fondue	FO	2471	0,0W							
Kitchen	Friteuse	FR	2490		0,327W						
Beverages & Breakfast	Toaster	AT	2509	0,03W							
Beverages & Breakfast	Toaster	AT	2514	0,05W							
Beverages & Breakfast	Toaster	AT	2515	0,0W							
Beverages & Breakfast	Toaster	AT	2589	0,0W							
Beverages & Breakfast	Toaster	AT	2590	0,0W							
Beverages & Breakfast	Toaster	AT	2620	0,0W							
Beverages & Breakfast	Toaster	AT	2621	0,0W							
eBBQ & Funfood	Sandwich-Automat	SA	2968	0,0W							
eBBQ & Funfood	Sandwich-Automat	SA	2969	0,0W							
Beverages & Breakfast	Eierkocher	EK	3163	0,21W							
Beverages & Breakfast	Eierkocher	EK	3164	0,0W							
Beverages & Breakfast	Eierkocher	EK	3165	0,0W							

								KA with insulated jug	KA with non-insulated jug	Other coffee maker
Category	Product-groupe	Code	Art.-No.	"Off-Mode"	"Standby-Mode"	"Standby-Mode with additional funktion"	"Time of switch equipment to power management"			
Beverages & Breakfast	Eierkocher	EK	3166	0.0W						
Beverages & Breakfast	Eierkocher	EK	3169	0.0W						
Haushalt / Beauty	Bügelaufomat	BA	3210	0,743W						
Haushalt / Beauty	Bügelaufomat	BA	3211							
Haushalt / Beauty	Bügelaufomat	BA	3234	0,06W						
Haushalt / Beauty	Bügelaufomat	BA	3243							
Haushalt / Beauty	Bügelaufomat	BA	3261	0W						
Beverages & Breakfast	Wasserkocher	WK	3401	0.0W						
Beverages & Breakfast	Wasserkocher	WK	3402	0.0W						
Beverages & Breakfast	Wasserkocher	WK	3409	0.0W						
Beverages & Breakfast	Wasserkocher	WK	3410	0.0W						
Beverages & Breakfast	Wasserkocher	WK	3411	0.0W						
Beverages & Breakfast	Wasserkocher	WK	3417	0.0W						
Beverages & Breakfast	Wasserkocher	WK	3418	0.06W		0.1W				
Beverages & Breakfast	Wasserkocher	WK	3420	0.0W						
Beverages & Breakfast	Wasserkocher	WK	3422		0.29W					
Beverages & Breakfast	Wasserkocher	WK	3427	0.00W						
Beverages & Breakfast	Wasserkocher	WK	3458	0.15W	0.22W					
Beverages & Breakfast	Wasserkocher	WK	3459	0.0W						
Beverages & Breakfast	Wasserkocher	WK	3462	0.00W						
Beverages & Breakfast	Wasserkocher	WK	3468	0.05W						
Beverages & Breakfast	Wasserkocher	WK	3469	0.00W						
Beverages & Breakfast	Wasserkocher	WK	3472	0.0W						
Beverages & Breakfast	Wasserkocher	WK	3473		0.39W					
Beverages & Breakfast	Wasserkocher	WK	3480		0.269W					
Beverages & Breakfast	Wasserkocher	WK	3483		0.160W					
Beverages & Breakfast	Wasserkocher	WK	3489	0.0W						
Beverages & Breakfast	Wasserkocher	WK	3494	0.0W						
Beverages & Breakfast	Wasserkocher	WK	3498	0.0W						
Kitchen	Joghurtbereiter	JG	3518	0.0W						
Kitchen	Joghurtbereiter	JG	3520	0.0W						
Kitchen	Joghurtbereiter	JG	3521		0.18W					
Kitchen	Citruspresse	CP	3535	0.0W						
Kitchen	Citruspresse	CP	3544	0.0W						
Kitchen	Entsafter	ES	3566	0.04W						
Kitchen	Entsafter	ES	3570	0.45W						
Kitchen	Entsafter	ES	3571	0.439W						
Beverages & Breakfast	Milchaufschäumer	SM	3579	0.39W						
Beverages & Breakfast	Milchaufschäumer	SM	3583							
Beverages & Breakfast	Milchaufschäumer	SM	3584	0.24W						
Beverages & Breakfast	Milchaufschäumer	SM	3585	0.46W						
Beverages & Breakfast	Milchaufschäumer	SM	3586	0.49W						
Beverages & Breakfast	Milchaufschäumer	SM	3587	0.32W	0.46W					

										KA with insulated jug	KA with non-insulated jug	Other coffee maker
										power consumption time	power consumption time	power consumption time
Category	Product-groupe	Code	Art.-No.	"Off-Mode"	"Standby-Mode"	"Standby-Mode with additional funktion"	"Time of switch equipment to power management"					
Beverages & Breakfast	Milchaufschäumer	SM	3588	0.24W								
Beverages & Breakfast	Milchaufschäumer	SM	3589	0.48W								
Beverages & Breakfast	Milchaufschäumer	SM	3590									
Kitchen	Folienschweißgerät	FS	3601									
Kitchen	Folienschweißgerät	FS	3604	0W								
Kitchen	Folienschweißgerät	FS	3610	0,40W								
Kitchen	Folienschweißgerät	FS	3628		0,93W							
Beverages & Breakfast	Wasserkocher	WK	3647									
Kitchen	Standmixer	SM	3707	0.179W								
Kitchen	Standmixer	SM	3718									
Kitchen	Standmixer	SM	3734	0.23W								
Kitchen	Standmixer	SM	3735	0.22W								
Kitchen	Standmixer	SM	3737	0.03W								
Kitchen	Stabmixer	SM	3770	0.23W								
Kitchen	Stabmixer	SM	3771	0.25W								
Kitchen	Stabmixer	SM	3772	0.25W								
Kitchen	Stabmixer	SM	3773	0.25W								
Kitchen	Stabmixer	SM	3774	0.25W								
Kitchen	Stabmixer	SM	3775	0.045W								
Kitchen	Handmixer	HM	3820	0.1W								
Kitchen	Handmixer	HM	3830	0.09W								
Kitchen	Handmixer	HM	3832	0.09W								
Kitchen	Handmixer	HM	3841	0.15W								
Kitchen	Handmixer	HM	3843	0.09W								
Kitchen	Küchenmaschine	KM	3865	0.32W								
Kitchen	Küchenmaschine	KM	3866	0.1W								
Kitchen	Küchenmaschine	KM	3867	0.17W								
Beverages & Breakfast	Kaffemühle	KM	3879	0.0W								
Beverages & Breakfast	Kaffemühle	KM	3880	0.36W								
Kitchen	Küchenmaschine	KM	3892	0.0W								
Kitchen	Küchenmaschine	KM	3898	0.41W								
Kitchen	Allesschneider	AS	3912	0.13W								
Kitchen	Allesschneider	AS	3915	0.2W								
Beverages & Breakfast	Toaster	AT	4321									
Beverages & Breakfast	Wasserkocher	WK	4322									
Beverages & Breakfast	Filterkaffeemaschine Glas	KA	4320	0,41						35min		
Beverages & Breakfast	Filterkaffeemaschine Glas	KA	4323	0,41						35min		
Beverages & Breakfast	Toaster	AT	4324									
Beverages & Breakfast	Wasserkocher	WK	4325									
Beverages & Breakfast	Filterkaffeemaschine Glas	KA	4478	0,36						40min		
Beverages & Breakfast	Filterkaffeemaschine Glas	KA	4479	0,36						40min		
Beverages & Breakfast	Filterkaffeemaschine Glas	KA	4808	0,46						37min		
Beverages & Breakfast	Filterkaffeemaschine Glas	KA	4810			0,77				36min		
Beverages & Breakfast	Filterkaffeemaschine Glas	KA	4813			0,42				36min		

								KA with insulated jug	KA with non-insulated jug	Other coffee maker
								power consumption time	power consumption time	power consumption time
Category	Product-groupe	Code	Art.-No.	"Off-Mode"	"Standby-Mode"	"Standby-Mode with additional funktion"	"Time of switch equipment to power management"			
Beverages & Breakfast	Filterkaffeemaschine Thermo	KA	4814			0,41		1min		
Beverages & Breakfast	Filterkaffeemaschine Glas	KA	4815	0,33				39min		
Beverages & Breakfast	Filterkaffeemaschine Glas	KA	4816	0,33				39min		
Beverages & Breakfast	Filterkaffeemaschine Glas	KA	4817	0,33				39min		
Beverages & Breakfast	Filterkaffeemaschine Glas	KA	4819	0,46				37min		
Beverages & Breakfast	Filterkaffeemaschine Glas	KA	4823	0,33				39min		
Beverages & Breakfast	Filterkaffeemaschine Glas	KA	4825	0,33				39min		
Beverages & Breakfast	Filterkaffeemaschine Glas	KA	4826			0,65			36min	
Beverages & Breakfast	Filterkaffeemaschine Thermo	KA	4835	0,34				5min		
Beverages & Breakfast	Filterkaffeemaschine Thermo	KA	4845	0,34				5min		
Beverages & Breakfast	Filterkaffeemaschine Thermo	KA	4847	0,34				5min		
Beverages & Breakfast	Filterkaffee-Vollautomat	KA	4849			0,88			Max. to 1 hour	
Beverages & Breakfast	Filterkaffee-Vollautomat	KA	4850			0,88			Max. to 1 hour	
Beverages & Breakfast	Filterkaffee-Vollautomat	KA	4851			0,88			Max. to 1 hour	
Beverages & Breakfast	Filterkaffee-Vollautomat	KA	4852	0,00		0,74		4:59	Max. to 1 hour, but warning in the IM.	
Beverages & Breakfast	Filterkaffee-Vollautomat	KA	4853	0,00		0,74		4:59	Max. to 1 hour, but warning in the IM.	
Beverages & Breakfast	Filterkaffee-Vollautomat	KA	4854	0,00		0,74		4:59	Max. to 1 hour, but warning in the IM.	
Beverages & Breakfast	Filterkaffee-Vollautomat	KA	4855	0,00		0,74		4:59	Max. to 1 hour, but warning in the IM.	
eBBQ & Funfood	Wurster	WT	5005							
Beverages & Breakfast	Filterkaffeemaschine Glas	KA	5762			0,78			38min	
Beverages & Breakfast	Filterkaffeemaschine Thermo	KA	5763			0,78		3min		
Beverages & Breakfast	Siebträger	KA	5978	0,36						25min
Beverages & Breakfast	Siebträger	KA	5995	0,39						23min
Beverages & Breakfast	Siebträger	KA	5997	0,20						30min
Florcare	Roboter	RB	7023		0,36W					
Florcare	Roboter	RB	7025		0,36W					
Florcare	Bodenstaubsauger mit Beutel	BC	7030	0W						
Florcare	Bodenstaubsauger mit Beutel	BC	7035	0W						
Florcare	Bodenstaubsauger mit Beutel	BC	7045	0W						
Florcare	Bodenstaubsauger mit Beutel	BC	7047	0W						
Florcare	Bodenstaubsauger mit Beutel	BC	7052	0W						
Florcare	Beutelloser Singlecyclone Sauger	CY	7088	0W						
Florcare	Beutelloser Singlecyclone Sauger	CY	7089	0W						
Florcare	Beutelloser Singlecyclone Sauger	CY	7103	0W						
Florcare	Handstaubsauger	HV	7130		0,15W					
Florcare	Handstaubsauger	HV	7140		0,19W					
Florcare	Dampfreiniger	SC	7142	0W						
Florcare	Handstaubsauger	HV	7144		0,056W					
Florcare	Dampfreiniger	SC	7145	0W						
Florcare	Handstaubsauger	HV	7146		0,05W					
Florcare	Handstaubsauger	HV	7147		0,05W					
Florcare	Kabellose 2-in1 Hand- und Stielsauger	HV	7151		0,37W					
Florcare	Kabellose 2-in1 Hand- und Stielsauger	HV	7152		0,09W					
Florcare	Kabellose 2-in1 Hand- und Stielsauger	HV	7154		0,09W					

								KA with insulated jug	KA with non-insulated jug	Other coffee maker
Category	Product-groupe	Code	Art.-No.	"Off-Mode"	"Standby-Mode"	"Standby-Mode with additional funktion"	"Time of switch equipment to power management"			
Floorcare	Kabellose 2-in1 Hand- und Stielsauger	HV	7155		0,05W					
Floorcare	Kabellose 2-in1 Hand- und Stielsauger	HV	7166		0,1W					
Floorcare	Kabellose 2-in1 Hand- und Stielsauger	HV	7168		0,1W					
Floorcare	Kabellose 2-in1 Hand- und Stielsauger	HV	7173		0,05W					
Floorcare	Kabellose 2-in1 Hand- und Stielsauger	HV	7175		tbd					
Floorcare	Kabellose 2-in1 Hand- und Stielsauger	SC	7177		0,06W					
Floorcare	Kabellose 2-in1 Hand- und Stielsauger	HV	7178		tbd					
Floorcare	Kabellose 2-in1 Hand- und Stielsauger	HV	7179		tbd					
Kitchen	Eismaschine	EZ	7405			0.49W				
Kitchen	Eismaschine	EZ	7406			0.49W				
Kitchen	Eismaschine	EZ	7407			0.56W				
Microwave & Toasting oven	Mikrowelle 2-in-1	MW	7751			0.58W				
Microwave & Toasting oven	Mikrowelle 3-in-1	MW	7752			0.6W				
Microwave & Toasting oven	Mikrowelle Solo	MW	7761	0.06W						
Microwave & Toasting oven	Mikrowelle 2-in-1	MW	7762	0.06W						
Microwave & Toasting oven	Mikrowelle 2-in-1	MW	7763			0.57W				
Microwave & Toasting oven	Mikrowelle 2-in-1	MW	7766	0.06W						
Microwave & Toasting oven	Mikrowelle 2-in-1	MW	7768	0.06W						
Microwave & Toasting oven	Mikrowelle Solo	MW	7770	0.05W						
Microwave & Toasting oven	Mikrowelle 2-in-1	MW	7771	0.06W						
Microwave & Toasting oven	Mikrowelle Solo	MW	7772	0.10W						
Microwave & Toasting oven	Mikrowelle 3-in-1	MW	7773			0.7W				
Microwave & Toasting oven	Mikrowelle 3-in-1	MW	7774			0.7W				
Microwave & Toasting oven	Mikrowelle 3-in-1	MW	7775			0.7W				
Microwave & Toasting oven	Mikrowelle 3-in-1	MW	7777			0.58W				
Microwave & Toasting oven	Mikrowelle 2-in-1	MW	7780	0.06W						
Microwave & Toasting oven	Mikrowelle 2-in-1	MW	7781	0.06W						
Microwave & Toasting oven	Mikrowelle Solo	MW	7782	0.06W						
Microwave & Toasting oven	Mikrowelle Solo	MW	7790	0.05W						
Microwave & Toasting oven	Mikrowelle 2-in-1	MW	7874	0.0W						
Microwave & Toasting oven	Mikrowelle Solo	MW	7885	0.06W						
Microwave & Toasting oven	Mikrowelle Solo	MW	7886	0.06W						
Microwave & Toasting oven	Mikrowelle Solo	MW	7888	0.06W						
Microwave & Toasting oven	Mikrowelle 3-in-1	MW	7918			0.55W				
Floorcare	Handstaubsauger	HV	7963		0,056W					
Floorcare	Kabellose 2-in1 Hand- und Stielsauger	HV	7966		0,09W					
Floorcare	Kabellose 2-in1 Hand- und Stielsauger	HV	7968		0,064W					
Haushalt / Beauty	Fusselrasierer	CS	7976							

								KA with insulated jug	KA with non-insulated jug	Other coffee maker
Category	Product-groupe	Code	Art.-No.	"Off-Mode"	"Standby-Mode"	"Standby-Mode with additional funktion"	"Time of switch equipment to power management"			
eBBQ & Funfood	Barbecue-Grill Tisch	PG	8106	0,001W		0,27W	5min			
eBBQ & Funfood	Barbecue-Grill Stand	PG	8107	0,001W		0,27W	5min			
eBBQ & Funfood	Barbecue-Grill Tisch	PG	8113		0,48W					
eBBQ & Funfood	Barbecue-Grill Tisch	PG	8114	0,001W		0,21W	5min			
eBBQ & Funfood	Barbecue-Grill Stand	PG	8117		0,48W					
eBBQ & Funfood	Barbecue-Grill Stand	PG	8118	0,001W		0,21W	5min			
eBBQ & Funfood	Barbecue-Grill Stand	PG	8137	0,001W		0,27W	5min			
eBBQ & Funfood	Barbecue-Grill Tisch	PG	8138	0,001W		0,27W	5min			
eBBQ & Funfood	Barbecue-Grill Stand	PG	8139	0,001W		0,27W	5min			
eBBQ & Funfood	Barbecue-Grill Stand	PG	8541	0,0W						
eBBQ & Funfood	Barbecue-Grill Tisch	PG	8554	0,01W						
eBBQ & Funfood	Barbecue-Grill Tisch	PG	8556	0,01W						
eBBQ & Funfood	Barbecue-Grill Tisch	PG	8564	0,19W						
eBBQ & Funfood	Barbecue-Grill Tisch	PG	8565	0,18W						
eBBQ & Funfood	Barbecue-Grill Stand	PG	8566	0,18W						
eBBQ & Funfood	Barbecue-Grill Tisch	PG	8567	0,18W						
eBBQ & Funfood	Barbecue-Grill Stand	PG	8568	0,18W						
eBBQ & Funfood	Barbecue-Grill Tisch	PG	8569	0,32W						
eBBQ & Funfood	Barbecue-Grill Tisch	PG	8575			0,65W				
Beverages & Breakfast	Filterkaffeemaschine Glas	KA	9263	0,41					35min	
Beverages & Breakfast	Toaster	AT	9264							
Beverages & Breakfast	Wasserkocher	WK	9265							
Beverages & Breakfast	Filterkaffeemaschine Thermo	KA	9306	0000				5min		
Beverages & Breakfast	Filterkaffeemaschine Thermo	KA	9307	0000				5min		
Beverages & Breakfast	Filterkaffeemaschine Thermo	KA	9309	0000				5min		
Beverages & Breakfast	Filterkaffeemaschine Thermo	KA	9314	0000				5min		
Beverages & Breakfast	Filterkaffeemaschine Thermo	KA	9315	0000				5min		
Kitchen	Standmixer	SM	9479	0,03W						
Beverages & Breakfast	Toaster	AT	9552							
Beverages & Breakfast	Wasserkocher	WK	9553							
Beverages & Breakfast	Filterkaffeemaschine Glas	KA	9554	0,33					39min	
Beverages & Breakfast	Wasserkocher	WK	9555							
Beverages & Breakfast	Filterkaffeemaschine Glas	KA	9572	0,33					39min	
Beverages & Breakfast	Toaster	AT	9573							
Beverages & Breakfast	Wasserkocher	WK	9574							
Beverages & Breakfast	Filterkaffeemaschine Glas	KA	9575	0,33					39min	
Beverages & Breakfast	Toaster	AT	9576	0,33					39min	
Beverages & Breakfast	Wasserkocher	WK	9577							
Kitchen	Allesschneider	AS	9578	0,12W						
Microwave & Toasting oven	Mikrowelle Solo	MW	9587							
Floorcare	Bodenstaubsauger mit Beutel	BC	9588	0W						
Floorcare	Handstaubsauger	HV	9589		0,19W					
eBBQ & Funfood	Raclette-Grill	RG	9645	0W						
eBBQ & Funfood	Raclette-Grill	RG	9670	0W						